

## ***040: Programming the EPIRB1/Pro with Programming Wand***

### **Introduction**

This technical bulletin provides guidance on how to achieve connection with the EPIRB1 and EPIRB1 Pro models using the programming wand and the beacon configuration software.

### **Method**

1. Ensure that the latest beacon configuration software is installed and closed down.
2. Put beacon into programming mode by holding the 'T' test key until the LED turns green (this takes approximately 10-15 seconds)
3. Once the LED is green, release the 'T' test key and then press it again quickly. The LED should turn red.
4. Hold the programming wand over the LED at the angle shown in the images.
5. Open the programming software.

Following this method should result in the programming wand successfully connecting to the beacon.

